



## WATCH HAND REMOVER PLUNGER TYPE





- Quick acting tool for removing all types of hands from watches.
- The tool is activated by pushing downwards on the plunger.
- Has a center post acting as a guide and also holds the hands after they have been removed.



